

VW Disposal Methods

All VW shall be disposed of per 40CFR Ch.1 761.60-64 which includes:

- VW that will no longer being used as part of the research project shall be stored in the lab in a plastic (closed) garbage bag inside a container with a lid for no more than one year
- VW will stored until PCB concentrations have been determined (characterization results).
- If the PCB concentrations are less than 1 ppm, the VW may be disposed of back at the decant facility where the sample was collected
- If the PCB concentrations are between 1-10 ppm, the VW should be disposed of in a limited purpose landfill
- If the PCB concentrations are between 10-50 ppm, the VW will require a source determination